

# Lofting Instructions

Territorial, Centennial, Wilkins



HOUSING &  
RESIDENTIAL LIFE

*Note: Rubber mallets can be checked out from the front desk.*



- 1** Remove mattress from frame and turn bed so  logo faces outward.



- 3** Use rubber mallet to detach metal frame and move to top notches. Secure in place with mallet.



- 2** Detach stabilizer bar using mallet.



- 4** Move stabilizer bar to opposite side and secure in the bottom notches.



- 5** Add mattress.

**Caution:** Be careful not to hit the sprinklers while lifting the bed, and ONLY attempt with at least 2 people (4 recommended).

**Need assistance?** If you need something repaired or replaced in your room, submit a Fix It request: [housing.umn.edu/FixIt](https://housing.umn.edu/FixIt)